

SPARE PARTS LIST

FSC200

ITEM	PART #	DESCRIPTION	ITEM	PART #	DESCRIPTION
1	200101	Hammer Face	26	200126	Pusher
2	200102	O-ring	27	200127	Screw,
3	200103	Screw,	28	200128	Feeder Spring
3A	200146	Washer,	29	200129	Staple Guide Plate
4	200104	Cap	30	200130	Screw,
5	200105	Screw	30A	200147	Washer, Lock
6	200106	Poppet Actuator	31	200131	Spring Pin
7	200107	O-ring	32	200132	Nose
8	200108	Gasket	33	200133	Blade Guide
9	200109	O-ring	34	200134	Screw
10	200110	Piston Stem	34A	200134A	Pin
11	200111	Poppet	35	200135	Wear Plate
12	200112	O-ring	36	200136	Magazine Body
13	200113	Poppet Seal	37	200137	Screw,
14	200114	Piston	38	200138	Spacer
15	200115	Pin	39	200139	Screw
16	200116	Driver Blade	40	200140	Screw
17	200117	O-ring	42	200142	Shoe
18	200118	Lock Nut	43	200143	Screw,
19	200119	Bumper	43A	200148	Washer, Lock
20	200120	Spring	44	200144	1/4" Adaptor Pad
21	200121	Body	45	200145	Screw
22	200122	Body Gasket	36U	200136U	Magazine Unit
23	200123	Handle			
24	200124	Air Plug			
25	200125	Handle Grip			